

Closed System Mass Balance

Closed recirculating heating and cooling water systems are designed to operate with minimal water losses. System water losses waste both water and treatment chemicals. Adding new makeup water may also introduce problem-causing contaminants that can lead to increased corrosion and fouling.

The white box in the mass-balance diagram on the right illustrates the boundary where water both enters and leaves the overall closed water system.

